# **DOCUS CEILING 2.0**

**INSTALLATION INSTRUCTIONS | APRIL 2023** 

# 2.0 LED


# Double LED module.

-locking ring

- inner cover

## 2.0 PAR16

Two bases are connected together by means of a spacer bracket.



Remove the mounting base plate from the LED module by loosening the socket screws and mount it on the ceiling with screws (screws are not included).

2.0 PAR16

### **FOR 2.0 PAR16**

**DIMENSIONS** 

2.0 LED

MOUNTING INSTRUCTION


Attach both bases to each other by using the bracket and screws (supplied with the cover), and mount them on the


FOR 2.0 LED

ceiling with screws (screws are not included).

# POWER CONNECTION

Connect to 220-240V. for LED





## FOR 2.0 LED


Attach the double LED module on the base plate with the socket screws.

- Attach the cover to the luminaire base by screwing the locking rings.
- **OPTIONAL** inner cover Put the inner cover in the outer cover by screwing.


With inner cover: max. 10W

### base plate dimensions

2.0 LED











#### **WEVER & DUCRÉ BV**

# **DOCUS CEILING 2.0**

**INSTALLATION INSTRUCTIONS | APRIL 2023** 







## DISMOUNTING AND RECYCLING INSTRUCTIONS only for 1.0 LED Light source & driver\*

- Unscrew the locking rings and remove the cover.
- Remove the four socket screws and disconnect the wires to dismount the LED module from the base.
- Loosen the screws and remove the diffuser(s) and reflector(s).
- Disconnect the wires, loosen the screws and remove the light source(s).
- \*For 2000-3000K variant: Loosen the wires and unscrew the driver(s) to remove it/them.



The light source is replaceable by an authorized

For advice contact your Wever & Ducré customer service contact point.



The driver can be replaced by the end user.\*

This luminaire contains a light source with the corresponding energy class:

colour temperature	Energy class
3000K	A A G
2700K 2000-3000K	A↑ F

\*only applicable on the 2000-3000K variant