



# KIOSK wall

INSTALLATION INSTRUCTIONS | OCTOBER 2024



## DIMENSIONS




## MOUNTING INSTRUCTION

**1** Remove the mounting base by loosening the socket screws and fix it to the wall with screws (screws are not included).


### 2 POWER CONNECTION

Connect to 220-240V.

Connect the earth cable.





For LED: always use a matching grommet based on the used 220-240V cable and the corresponding type in the overview table. for example:



**3** Fix the fixture to the mounting base with the socket screws.

## Mounting base:





Always use a matching grommet in the overview table.

	A	B	C
<p>use pin to make hole, not a knife</p>			
CABLE			
TYPE	ROUND H05RN-F H07RN8-F H07RN-F	ROUND H05RN-F	ROUND
OUTSIDE Ø	min 6.8mm max 8.9mm	min 5mm max 6.8mm	min 1.5mm max 2.6mm
CONDUCTION SECTION	2or3x 0.75mm <sup>2</sup> 2or3x 1.0mm <sup>2</sup> 2or3x 1.5mm <sup>2</sup>	2or3x 0.75mm <sup>2</sup> 2x 1.0mm <sup>2</sup>	0.75mm <sup>2</sup> 1.5mm <sup>2</sup>

# KIOSK wall


INSTALLATION INSTRUCTIONS | OCTOBER 2024




## DISMOUNTING AND RECYCLING INSTRUCTIONS

### Light source & driver

- 1 Dismount the fixture from the wall by loosening the socket screws and the wiring.
- 2 Remove the driver by pulling and disconnect the wires.
- 3 Break the glass(es).
- 4 Take out the lens(es) and unscrew the light source(s) to remove it/them.



The light source is not replaceable.



The driver can be replaced by the end user.



This luminaire contains a light source with the energy class E.



WEVER & DUCRÉ  
LIGHTING

WEVER & DUCRÉ BV

Spinnerijstraat 99/21, 8500 Kortrijk, Belgium  
weverducre.com